

#### What is a socket?

- Software interface for network communication
- A (virtual) connection between 2 applications (client and server)
- Identifies a specific network connection
   Source/Destination ports, Source/Destination IPs
- You can read and write from sockets in Python, like files



# Types 01101110

- UDP socket
  - Send and receive UDP packets
- TCP socket

Manage TCP connections (listen, connect, close connection)

Send data over a TCP connection



## TCP sockets

Server

Listening socket - waiting for incoming connections (SYN)

After connection (SYN, SYN-ACK, ACK) - creates a <u>new</u> communication socket for

this specific connection


The original socket continues listening for new connection requests

Client

Connects to a server (IP + port)

After connecting - the socket is used for this specific connection





#### TCP client - connect

```
import socket

SERVER_IP = '192.168.1.1'
SERVER_PORT = 1234

sock = socket.socket()  # default is TCP
sock.connect((SERVER_IP, SERVER_PORT))
```



#### TCP server - bind and listen

- <u>bind</u> connect the socket locally to a port and IP (0.0.0.0 wait for connections on all available interfaces)
- <u>listen</u> start waiting for incoming connections

```
import socket

SERVER_IP = '0.0.0.0'
SERVER_PORT = 1234

sock = socket.socket()  # default is TCP
sock.bind((SERVER_IP, SERVER_PORT))
sock.listen()
```



## TCP server - accept

accept - wait for incoming connection (blocking).

When there's a connection, returns a new socket for this connection, and the client's address (IP, port)

```
con, addr = sock.accept()
print('Incoming connection from', addr)
# con is the new socket for this connection
```



# TCP client/server-send data

<u>send</u> - sends binary data (bits and bytes).
 Before we send text, we have to encode it to binary with encode()

```
data = 'Hello!'
sock.send(data.encode())
```



## TCP client/server - receive data

receive - receives binary data (bits and bytes).
 We have to specify the buffer size (maximum bytes to receive).
 Before we print/use it, we have to decode from binary to text with decode()

```
data = sock.recv(1024) # buffer size
print(data.decode())
```



# TCP client example

<u>close</u> - closes the connection (sends FIN).

```
import socket

sock = socket.socket()
sock.connect(("127.0.0.1", 1337))
sock.send("Hello world!".encode())
data = sock.recv(1024)
print(data.decode())
sock.close()
```

## TCP server example

```
import socket

sock = socket.socket()
sock.bind(("0.0.0.0", 1337))
sock.listen()

con, addr = sock.accept()
con.send("Hello world!".encode())
data = con.recv(1024)
print(data.decode())
sock.close()
```



## UDP sockets

- No connection just send and receive data
- We have to specify the socket type

```
socket.AF_INET - means that it's a connection over IP socket.SOCK_DGRAM - means that it's UDP (TCP is: socket.SOCK_STREAM)
```

```
import socket
sock = socket.socket(socket.AF_INET, socket.SOCK_DGRAM)
```



## UDP client example

- sendto send data to an arbitrary IP and port.
- <u>recvfrom</u> returns the received data and the address of the sender.

```
import socket

sock = socket.socket(socket.AF_INET, socket.SOCK_DGRAM)
 sock.sendto("Hello world!".encode(), ("127.0.0.1", 1337))
 data, addr = sock.recvfrom(1024)
 print("Message from:", addr)
 print(data.decode())
 sock.close()
```



## UDP server example

Same as client, except we must bind the socket to an IP and port before
we can receive data.

```
import socket

sock = socket.socket(socket.AF_INET, socket.SOCK_DGRAM)
sock.bind(("0.0.0.0", 1337))
data, addr = sock.recvfrom(1024)
print("Message from:", addr)
print(data.decode())
sock.sendto("Hello world!".encode(), addr)
sock.close()
```



#### What did we learn?

- What is a socket
- TCP sockets

Client - connect

Server - bind, listen, accept

Send and receive

**UDP** sockets

sendto and recyfrom

